

Helicopter Communications Switchboard

Com 1 – communicates with the Tower

Com 2 – communicates with Mercy Air Dispatch

VOX – adjusts microphone sensitivity

ICS – adjusts inter-cockpit volume

RX – adjusts radio volume